




Ordering spares / Ersatzteil - Regelung / Pièces de rechange /
 Parti di ricambio / Lista de recambios / Onderdelen bestellen
 (NL/B) / Κωδικό Ανταλλακτικών / Bestilling af reservedele
 / Beställning av reservdelar / Bestilling av reservedeler /
 Резервни части / Запчасти / Części zapasowe / Piese de
 schimb / Rendelhető alkatrészek / Запасні частини / Резервни
 делови / Резервни делови / Atsarginių dalių / Tellitavad varu-
 osad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek
 parça siparişi / Nadomestni deli

XX = AA, AD,


- 1 - B 961779 NU
- 2 - A 963751 NU
- 3 - A 861446 NU
- 4 - B 961780 XX
- 4a - B 961781 XX
- 5 - A 963477 NU



Ideal Standard International NV
 Corporate Village – Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium
<http://www.idealstandardinternational.com>








JOY NEO








Ideal Standard

03.2022 / B565169





 P	bar		 
 T	°C	