





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb /
 Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX = AA, ...


Pos.	Part No.
1	A 963 131 NU
2	A 963 132 NU
3	A 963 146 NU
4	A 960 890 NU
5	A 960 891 NU
6	A 960 706 NU
7	A 960 500 NU
8	A 960 893 XX
9	A 960 895 NU
10	A 962 390 XX
11	A 962 065 XX
12	A 960 704 NU
	A 962 476 NU
13	A 960 705 XX



Ideal Standard

MELANGE
 A 4719 ..



1220 / A 868 761
 Made in Germany








Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





	0	1	2	3	4	5	6	7	8	9
50°C	16°C	49,5	49,5	48	46	42,5	41	37	33,5	31
65°C	16°C	65	65	63,5	60,5	57	53,5	49	44,5	39
81°C	16°C	81	81	78,5	73	69	63,5	56	49	42,5



P	bar	MAX. 10	5	Q
0,5	1	MAX. 80	65	(3 bar)
T	°C	55	25	l/min